

## Attention Installer

The Blaupunkt Systems 1, 2B, 3A, 3B and 4 radios are designed to suit the Holden range of vehicles. Each vehicle type has different characteristics, for example two and four speakers. Radios fitted to export vehicles also have different FM and AM settings to suit their respective country requirements. The radio also has internal settings according to which type of vehicle it is fitted to. The radio will only work at its best if these settings are programmed to the correct vehicle type.

TECH2 contains codefiles to suit each radio and vehicle. Follow the TECH2 instructions for Code Index Programming and choose the codefile to suit the vehicle type and radio type that is being fitted. It is recommended that each radio be programmed when it is first fitted, regardless of whether the operation appears correct. Only then can you be sure that the radio will function normally.

TECH2 Codefiles to use:

Vehicle applications	Radio types	Code Index/Version No.
8VK 35, 37, 43, 69 & U1C & RHD	Sys 1, Sys 2B, Sys 3A, Sys3B	007/01
8VK 35, 69 & UN0 & RHD	Sys 1, Sys 2B, Sys 3A, Sys3B	007/01
8VK 35, 37, 43, 69 & U1V & RHD	Sys 1, Sys 2B, Sys 3A, Sys3B	007/01
8VL 00 & U1V & RHD - XU6,XY2, XY9, XW1, XW5	Sys 1, Sys 2B, Sys 3A, Sys3B	007/01
8VK 35, 37, 69 & U1C & E05	Sys 1GCC, Sys 3AGCC, Sys 3BGCC	008/01
8VK 35, 37, 69 & U1V & E05	Sys 1GCC, Sys 3AGCC, Sys 3BGCC	008/01
8VL 00 & U1V & E05	Sys 1GCC, Sys 3AGCC, Sys 3BGCC	008/01
8VK 03, 80 & U1C & RHD	Sys 1 2-spkr, Sys 3 2-spkr	009/01
8VK 03, 80 & U1V & RHD	Sys 1 2-spkr, Sys 3 2-spkr	009/01
8VL 69 & U1X & XU6,XY2, XY9, XW1, XW5	System 4	0010/01
8VX 37,69 & U1X & RHD	System 4	0010/01
8VX 37 & U1X & E05	System 4GCC	0011/01
8VX 69 & U1X & B08	System 4GMB	0012/01

### NOTE:

If you do not know what vehicle the radio is programmed for, **RE-PROGRAM IT!** After you have completed all programming, enter the PIN code into the radio using the preset buttons. The PIN is given in the radio passport. For example, if the PIN is "4613", you should then press the preset buttons in the following order: 4, 6, 1 and lastly 3.

**Refer Page 2 of 2 before installation to vehicle**

**ITEMS TO BE REMOVED  
BEFORE INSTALLATION TO VEHICLE  
For System  
3A,3B,3AGCC,3BGCC,4,4GCC,4GMB**

*(View from Top of Radio)*

- ① **Rubber Spacer (2x) - Remove tape and spacer.**
- ② **Transportation Screw - Turn to unlock then remove.**
- ③ **Radio Passport - Remove & keep in a safe place.**

